


REFLECTIONS DENOISER

ANTON SCHREINER

DOMINIK BAUMEISTER












CLASSIFICATION



PIPELINE



PIPELINE



PIPELINE

- Reproject and estimate variance – ffx_denoiser_reflections_reproject.h
 - FFX_DNSR_Reflections_Reproject
- Variance Guided Edge aware filter – ffx_denoiser_reflections_prefilter.h
 - FFX_DNSR_Reflections_Prefilter
- Accumulate – ffx_denoiser_reflections_resolve_temporal.h
 - FFX_DNSR_Reflections_ResolveTemporal

PIPELINE

Intersection Pass




Intersection result

Reprojection Pass




Reprojected result

Spatial denoiser Pass




Spatially denoised result

Temporal denoiser Pass



Temporally denoised result



Reprojected variance



Spatially denoised variance result



Temporally denoised variance result



NumSamples



8x8 average

INTERNAL BUFFERS

- 3X Per pixel Signal buffers **R16G16B16A16_FLOAT** 24 bytes/pixel
 - 2X ping pong for denoiser and 1 for reprojection
 - Only 3 channels used
- 4X Per pixel Guide buffers **R16_FLOAT** 8 bytes/pixel
 - 2X ping pong for NumSamples and Variance
- 2X Per tile(8x8) avg radiance **R16G16B16A16_FLOAT** 1/4 bytes/pixel
 - Ping pong for radiance mip

Total: ~32 bytes per pixel for internal buffers (~64MB @ 1080p)

REPROJECTION FAST PATH

Perfect mirror parallax
reprojection


Current sample and
9x9 neighborhood

Pick one


Surface motion vector
reprojection + extra signal
distance check based on
neighborhood statistics to
avoid ghosting

REPROJECTION SLOW PATH

Neighborhood of the history sample
Helps with jitter




Manual bilinear interpolation
Helps on boundaries



This texel belongs to a different surface
And gets 0 weight


REPROJECTION




Surface motion
vector reprojection

Parallax
reprojection

REPROJECTION: DISOCCLUSION DETECTION



Disoccluded area
Due to
movement/animation.
NumSamples is set to 1.



REPROJECTION: 8X8 AVERAGE


Fast group local computation of 3rd 8x8 mip level
Weighted sum removes energy



8x8 average radiance is
used for low sample
areas and to filter
outliers

SPATIAL DENOISING


16 samples in the 7x7 region for edge aware blur
Weights depend on the similarity to the 8x8 average



Intersection results + variance




8x8 average



TEMPORAL ACCUMULATION


Spatially denoised result



Reprojected result



Use 9x9 gaussian region statistics to clip history
Accumulation depends on the NumSamples target:
 $\text{Weight} = 1 / (\text{NumSamples} + 1)$
Mix-in raw 8x8 average for points with short history



DEPENDENCIES

- Depth + history
- Roughness + history
- Normals + history
- Motion vectors



REFERENCES

- Nvidia: Fast Denoising With Self-Stabilizing Recurrent Blurs 2020
- EA: Stochastic Screen-Space Reflections 2015

DISCLAIMER

DISCLAIMERS

The information contained herein is for informational purposes only and is subject to change without notice. While every precaution has been taken in the preparation of this document, it may contain technical inaccuracies, omissions and typographical errors, and AMD is under no obligation to update or otherwise correct this information. Advanced Micro Devices, Inc. makes no representations or warranties with respect to the accuracy or completeness of the contents of this document, and assumes no liability of any kind, including the implied warranties of noninfringement, merchantability or fitness for particular purposes, with respect to the operation or use of AMD hardware, software or other products described herein. No license, including implied or arising by estoppel, to any intellectual property rights is granted by this document. Terms and limitations applicable to the purchase or use of AMD's products are as set forth in a signed agreement between the parties or in AMD's Standard Terms and Conditions of Sale.

© 2021 Advanced Micro Devices, Inc. All rights reserved. AMD, the AMD Arrow logo, EPYC, Radeon, Ryzen, and combinations thereof are trademarks of Advanced Micro Devices, Inc. in the United States and/or other jurisdictions. Other names are for informational purposes only and may be trademarks of their respective owners.